Wiring Diagram for Single Phase Submersible Turbine Pump controller models STP–SC (120V coil) & STP–SCB (240V coil). (AC, Master–Slave, or Master–Slave & AC Configurations)